

07-04, dne 13.04. 2021

EN – Padlock manual RV.621.CRN

Set your own code combination

1. The factory code is 0-0-0-0.
2. Set the factory code 0-0-0-0 on the front of the lock. The code has to be in line.
Warning: The line is only on one side of the lock.
3. Pull up the shackle of the lock.
4. Switch the pin to "SET" in the lower part of the lock.
5. Set your own code combination.
6. Switch the pin to "OFF" in the lower part of the lock.
7. New code combination is set now.

In case of need, you can repeat the steps 1-7 anytime.

Obr. č.1

