

07-03, 9.3.2021

## EN - Manual for chain code lock RR.732.6X900.CRN

### Manual for setting own code combination

1. On the dial (in axis) set the code combination 0-0-0-0-0 and disconnect the lock - „A”.
2. Turn the disc 90 degrees clockwise - „B” - and set your own code combination.
3. Turn the disc back to the original position - „B” (anticlockwise).

The new code combination is set now!

In case of need is possible to repeat the steps 1-3 anytime.

